
Lecture 21: Out-of-Order, Cache Hierarchies

- Today's topics:
 - Out of order processors wrap-up
 - Cache access intro and details

An Out-of-Order Processor Implementation



Example Code

Completion times	with in-order	with ooo
ADD R1, R2, R3	5	5
ADD R4, R1, R2	6	6
LW R5, 8(R4)	7	7
ADD R7, R6, R5	9	9
ADD R8, R7, R5	10	10
LW R9, 16(R4)	11	7
ADD R10, R6, R9	13	9
ADD R11, R10, R9	14	10

Cache Hierarchies

- Data and instructions are stored on DRAM chips DRAM is a technology that has high bit density, but relatively poor latency – an access to data in memory can take as many as 300 cycles today!
- Hence, some data is stored on the processor in a structure called the cache – caches employ SRAM technology, which is faster, but has lower bit density
- Internet browsers also cache web pages same concept

Memory Hierarchy

As you go further, capacity and latency increase

Registers 1KB 1 cycle L1 data or instruction Cache 32KB 2 cycles

L2 cache 2MB 15 cycles Memory 16GB 300 cycles


Disk 1 TB 10M cycles

Locality


- Why do caches work?
 - Temporal locality: if you used some data recently, you will likely use it again
 - Spatial locality: if you used some data recently, you will likely access its neighbors
- No hierarchy: average access time for data = 300 cycles
- 32KB 1-cycle L1 cache that has a hit rate of 95%:
 average access time = 0.95 x 1 + 0.05 x (301)
 = 16 cycles

Accessing the Cache

Accessing the Cache



The Tag Array



Example Access Pattern

